

# Manual Wall & Ceiling Mounted Projection Screens

## Model C™ Extra Heavy Duty



### Product Features

Wall or ceiling mount projection screen. Surface Matte White with black masking borders standard. Flame retardant and mildew resistant fabric, mounted on ball bearing rigid steel spring roller. Fabric is permanently attached to roller. Case is white powder coated 21-gauge steel, with flat back. Heavy duty end caps conceal roller ends with steel inner plates supporting roller and providing additional case strength. End caps form sturdy brackets for wall or ceiling installations. The bottom of the screen is formed into a pocket to hold a tubular metal slat. A steel pull bail is attached to the slat. The ends of the slat are protected by heavy-duty plastic caps. Bumper stops are built into the case to prevent slat wedging inside case. Includes a 1.8mtr pull cord with plastic knob.

#### VIDEO (4:3) FORMAT - DIMENSIONS

Viewing Area	Nominal Diagonal	Case Length	Shipping Weight
H x W mm	Inch	mm	Kg
1750 x 2340	120	2520	22.7
1980 x 2640	130	2830	25.4
2210 x 2950	150	3130	26.3
2670 x 3560	180	3740	31.3

#### HDTV (16:9) FORMAT - DIMENSIONS

Viewing Area	Nominal Diagonal	Case Length	Shipping Weight
H x W mm	Inch	mm	Kg
1315 x 2340	106	2620	22.2
1485 x 2640	119	2830	25.0
1660 x 2950	133	3130	28.1
2000 x 3560	159	3740	31.3



#### SQUARE FORMAT - DIMENSIONS

Viewing Area	Case Length	Shipping Weight
H x W mm	mm	Kg
2400 x 2400	2520	22.7
2740 x 2740	2830	26.3
3050 x 3050	3130	29.5
3660 x 3660	3740	35.8

Distributed By:



# Manual Wall & Ceiling Mounted Projection Screens

## Model C™ Extra Heavy Duty



### Product Features






#### Suggested Installation Methods

##### Wall Mounting

1. Select fasteners of proper type for wall or ceiling involved.
2. Install fasteners through proper openings provided in back side of end caps.
3. Attach screen securely to studding or other solid surface - never to plaster only.
4. MAKE SURE SCREEN IS MOUNTED LEVEL.

##### Ceiling Mounting

1. Heavy screw hooks may be installed into wooden joists. Other types of hooks or chain may be used for other ceilings or for stage installations.
2. Insert hooks or chain through proper openings provided in sides of end caps. Screen must hang so that the flat back of case is perpendicular to floor.
3. MAKE SURE THE SCREEN IS MOUNTED LEVEL.



##### To Open Screen

Pull down on pull bail until desired picture area is obtained. Lock into position as on a window shade. Be sure surface is locked before releasing.

##### To Re-Roll Your Picture Surface

The Model C operates on the same principle as a window shade. Pull down about 15 cm to disengage the locking pawl and start the fabric up firmly and quickly.

Large picture surfaces are heavy and will start up too slowly to prevent the locking pawl from catching unless help is provided, so keep picture surface moving briskly.

Should the locking pawl catch, pull the picture surface down about 15 cm and start the surface up rapidly.

However, do not permit the picture surface to roll up uncontrolled, particularly the last half metre. Allowing the bottom slat to strike the case uncontrolled may result in severe damage to your screen. Use the cord provided for control.

##### Precision Seaming

Large screens will have one or more horizontal seams. Seams are standard and necessary in large size screens since surfaces are limited to the available fabric size.

Da-Lite Perma-Sealed seams are made by butting carefully matched edges of two panels together and fastening with special tape that is sealed to the reverse side. These seams are guaranteed not to separate. Seams in a picture surface should not be construed as patched or defective. In use, the seams will be virtually invisible in the projected picture.

##### Protect Your Screen

Before re-rolling surface into case, examine both front and back of surface to be sure they are free of foreign matter.